



The Volt Dropper

Work Hard. Camp Easy.

Product Manual Version: 1.0

Release Date: June 2025

📦 Designed, Tested & Assembled in Australia

Built for Aussie conditions

Nax Voltage Store

Brand: Max Voltage Store

Website: www.maxvoltagestore.com.au Support: support@maxvoltagestore.com.au

ABN: 56597760054



Contents:

The Volt Dropper	1
Work Hard. Camp Easy.	1
Contents:	2
1. Introduction	3
2. What Is The Volt Dropper?	3
3. Safety Information	4
⚠ General Safety	4
Electrical Safety	5
Battery Safety	5
Protection Features	5
4. Specifications	6
6. Setup Instructions	6
Step 1: Insert the Battery	6
Step 2: Select and Connect Your Output	7
Step 3: Adjust Voltage (If Needed)	7
✓ Step 4: Power Up	7
7. Operating Tips & Best Practices	7
🧊 For Fridge Use	7
Battery Swaps	8
Temperature & Conditions	8
☆ Voltage Tuning	8
Connection Safety	8
8. Troubleshooting	9
Problem: No Power / LED Display Off	9
Problem: Device Turns Off During Use	9
Problem: Appliance Not Powering On	10
Problem: LED Display Flickers or Voltage Drops	10
9. Warranty & Support	11
2-Year Warranty – Built to Last, Backed by Us	11
What's Covered:	11
What's Not Covered:	11
Warranty Process:	11
10. Legal & Safety Notices	12
⚠ Safety Warnings	12
Disclaimer	12
- Compliance	12




1. Introduction

Thank you for choosing The Volt Dropper.

This compact, rugged device is designed to power your 12V appliances straight from your 18V lithium-ion power tool batteries — no vehicle wiring, no idling, and no hassle.

Whether you're out bush camping, fishing on the coast, enjoying a day at the golf course, or just escaping to the great outdoors, The Volt Dropper gives you reliable, portable power wherever you go.

2. What Is The Volt Dropper?



The Volt Dropper is a 12V DC converter that transforms 18–20V tool battery power into a stable, adjustable 12V output (5V–13V), capable of running common gear like:

- Car fridges
- LED camp lights
- 12V fans



- Air pumps
- Phone chargers (with a 12V adapter)

It's built to handle Australia's harshest environments, with multiple output options and full electrical protection to keep your gear running safely.

3. Safety Information

Please read this section carefully before using The Volt Dropper. Improper use can lead to equipment damage or personal injury.

General Safety

- Only use The Volt Dropper with 18V–20V lithium-ion power tool batteries from supported brands.
- Do not expose the unit to water, excessive moisture, or direct rain.
- Do not operate in explosive or highly flammable environments.
- Keep out of reach of children.

Electrical Safety

- Ensure connected devices do not exceed 10A total draw.
- Only use 12V DC appliances not compatible with 240V AC devices.
- Always verify polarity and voltage before connecting any appliance.
- Allow the unit to **cool down** between extended uses if operating at high loads.

Battery Safety

• Do not insert batteries that are damaged, swollen, or leaking.



- Never leave batteries attached for long-term storage.
- Remove battery after use to avoid unnecessary discharge or overheating.
- Always use batteries within their original manufacturer's safety guidelines.

Protection Features

The Volt Dropper includes built-in protection for:

- Overload
- Over-current
- Short circuit
- Low voltage
- No-load operation

If a protection mode is triggered, disconnect all devices and remove the battery. Wait 30 seconds before reconnecting.

4. Specifications

Feature	Details
Input Voltage	18V–20V DC (Lithium-ion tool batteries)
Output Voltage	12V DC (adjustable range: 5V–13V)
Max Output Current	10A
Efficiency	≥ 95%
Output Display	Digital LED readout (real-time output voltage)
Battery Compatibility	Makita, Milwaukee, DeWalt, Ozito, Bosch, Ryobi (with adapter)
Output Connector Options	50A Anderson-style plug (with waterproof cap) OR 12V cigarette lighter socket
Protection Features	Overload, over-current, low voltage, no-load, short circuit



Cable Construction PVC sleeving and reinforced plug sheath for durability

Operating Environment -10°C to 45°C, dry environments only

6. Setup Instructions

Follow these steps to safely connect and begin using your Volt Dropper:

Step 1: Insert the Battery

- 1. Align your **18V lithium-ion battery** with the terminal on the Volt Dropper.
- 2. Push down until the battery clicks into place securely.
- 3. Ensure a snug fit the unit should not wobble or disconnect easily.

Step 2: Select and Connect Your Output

Depending on your model, connect your 12V appliance to one of the following:

- Anderson Plug for rugged appliances like fridges or lighting systems.
- 12V Cigarette Socket for standard car accessories like fans or pumps.

Step 3: Adjust Voltage (If Needed)

- 1. Locate the **adjustment dial** or buttons (varies by model).
- 2. Turn or press to fine-tune the **output voltage between 5V and 13V**.
- 3. The digital LED display will show the live output voltage.
 - ⚠ Default output is 12V ideal for most car fridges and accessories.

Step 4: Power Up



Once your appliance is connected and the voltage is set:

- The LED display will illuminate.
- Your connected device should now be receiving power.

7. Operating Tips & Best Practices

To get the most out of your Volt Dropper and extend its lifespan, keep the following tips in mind:

🧊 For Fridge Use

- A typical 12V car fridge draws ~1 amp per hour.
- A **6Ah tool battery** can run a fridge for **up to 8–10 hours**, depending on:
 - Fridge brand & model
 - o Ambient temperature
 - o How often the lid is opened
 - o Amount and type of contents inside

Battery Swaps

- Keep a charged spare battery on hand for longer trips.
- Swap batteries out **before they're fully drained** to avoid triggering low-voltage protection.
- Remove the battery when not in use to avoid passive drain.

Temperature & Conditions

• Best operating range: -10°C to 45°C



- Avoid direct sunlight or hot surfaces
- · Keep away from water, rain, and mud

☼ Voltage Tuning

- Most users will leave the output at 12V, which suits fridges, lights, and pumps.
- Lower voltages (5V–9V) may be useful for small fans or USB adapters.
- Always double-check your appliance's input rating before adjusting.

Connection Safety

- Ensure connectors (Anderson or Cigarette) are securely fitted.
- Do not exceed the 10A maximum current draw this can trigger protection shutdown.

8. Troubleshooting

If you're having issues with your Volt Dropper, refer to the guide below for quick solutions.

Problem: No Power / LED Display Off

Possible Causes:

- Battery is not seated properly
- Battery is flat or faulty
- Battery brand not supported or adapter not connected

Solutions:

Remove and reinsert the battery firmly



- Try a fully charged battery
- Check for compatibility (Ryobi requires adapter)

♠ Problem: Device Turns Off During Use

Possible Causes:

- Battery is depleted
- Output current exceeds 10A
- Overheat or protection mode triggered

Solutions:

- Replace or recharge battery
- Check appliance current draw
- Let unit cool, then reconnect



Problem: Appliance Not Powering On

Possible Causes:

- Appliance not rated for 12V DC
- Faulty appliance or cable
- Incorrect output selected

Solutions:

- Confirm voltage rating on your device
- Test with another known-working appliance
- Adjust voltage output if needed



Problem: LED Display Flickers or Voltage Drops

Possible Causes:

- Overload condition
- Low battery voltage
- Loose connection at output

Solutions:

- Disconnect and test with a smaller load
- Replace battery with fully charged one
- Reseat connector and try again

If the issue persists after trying the above, reach out to us at **support@maxvoltagestore.com** — we're happy to help.

9. Warranty & Support

2-Year Warranty - Built to Last, Backed by Us

Every Volt Dropper is covered by a **2-year warranty** from the date of purchase. We stand by our products and will repair or replace any unit that fails due to defects in **materials or workmanship** during normal use.

What's Covered:

- Faulty internal components
- Malfunctioning voltage regulation
- Display or output failures not caused by misuse



Nhat's Not Covered:

- Damage from misuse, water ingress, or modification
- Wear and tear from abnormal conditions (e.g. corrosion, impact)
- Issues caused by unsupported batteries or overloading

Warranty Process:

- 1. **Contact us** at support@maxvoltagestore.com with your order number and issue description.
- 2. If approved, you'll be asked to **ship the faulty unit back** to us (at your expense).
- 3. Once received and inspected, we'll send you a **replacement unit** (you'll also cover the shipping cost for the replacement).
- 4. If repairable, we may opt to repair and return the original unit.

If you have questions or need help with your Volt Dropper, don't hesitate to reach out — we're here to help.

10. Legal & Safety Notices

Safety Warnings

- Always use the Volt Dropper with compatible 18V lithium-ion batteries from Makita, Milwaukee, DeWalt, Bosch, Ozito, or Ryobi (with adapter).
- Do not exceed the maximum output current of 10A.
- Only use in **dry**, **ventilated environments** this product is **not waterproof**.
- Do not tamper with or attempt to modify the internal electronics.
- Disconnect the battery when not in use or before adjusting wiring connections.
- Keep out of reach of children.



Disclaimer

Max Voltage Store is not responsible for any damage caused by improper use, overloading, or use with incompatible devices or batteries. Always check your appliance's power requirements before use.

Compliance

This product has been designed and tested for compliance with local safety and performance standards. Intended for recreational and light commercial use only.